

Section II
Group Assembly Parts List

FIGURE AND INDEX NO.	PART NUMBER	DESCRIPTION	UNITS PER ASSY	USABLE ON CODE						
				1	2	3	4	5	6	7
101 -		FUEL SELECTOR VALVE AND CONTROLS INSTALLATION SEE FIG 96 FOR NHA								NP
-1	1426029-6	VALVE ASSY-FUEL SELECTOR	2							C
-2	89-15-1	HANDLE AND SHAFT ASSY-MATCHED SET ONLY ATTACHING PARTS	1							
	NAS561PF3-10	PIN-ROLL	1							
-3	MS16624-37N	RING-SNAP								
-4	D1-13-1	SPRING	1							
-5	S272-208	BALL								1
-6	MS35207-259	SCREW	6							
	MS35333-39	HASHER-LOCK	6							
-7	83-12-1	GASKET								1
-8	2-12	O-RING	1							
-9	A7-14-1	CAN								1
-10	A9-15-1	SLEEVE ATTACHING PARTS	1							
	NAS561PF3-6	PIN-ROLL	1							
-11	1516004-1	GEAR BOX ASSY-LH								
	1516004-2	GEARBOX ASSY - RH (WEU 1516004-6)	1							
	1516004-4	GEARBOX ASSY - RH (WEU 1516004-6)	1							
-12	1516004-5	GEAR BOX ASSY-DUAL-LH VALVE	1							
-13	1516004-6	GEAR BOX ASSY-DUAL-RH VALVE	1							
-14	1528002-3	GEAR BOX ASSY-FUEL SELECTOR ATTACHING PARTS	1							
	MS35207-245	SCREW	2							
-15	MS21055L06	NUTPLATE								BB
-16	1516115-1	SWITCH PLATE ATTACHING PARTS	2							
	1516105-1	SPACER	1							
	MS35206-230	SCREW	1							
	AN960-6	HASHER	1							
-17	1516106-2	---S---								
	NAS561C2-10	CAM ATTACHING PARTS	2							
		PIN	1							
-18	1516046-1	---S---								
-19	1516027-1CP	DELETED-NEVER USED	1							AAA
	MS35206-245	PLATE ASSY-UPPER RH	1							
	MS24693S50	PLATE ASSY-UPPER RH ATTACHING PARTS	1							
-20	1516046-2	SCREW	3							AA
	1516009-3	SCREW	1							
	MS20392-1C25	LEVER ASSY-RH	1							
	MS24665-69	LEVER-LH ATTACHING PARTS	1							
	AN960-4L	PIN-STRAIGHT	1							
		PIN-COTTER	1							
		HASHER	1							AR
-21	USMSW	---S---								
	MS35206-321	SWITCH ATTACHING PARTS	3							
	AN960-3	SCREW	2							
		WASHER	2							
		---S---								
		CONTINUED								